

Adhesive Recommendations

floors@home | floors@work
Herringbone | Chevron | Groutline



To achieve optimal placement and adhesion results, we recommend the wet set procedure using one of the following products:

Uzin KE 66
Wulff Supra-Strong & Ultra-Strong
Wakol D3320 & Wakol D3318 MultiFlex
Bostik Findley Power-Elastic
Thomsit K 188S
Schönox Durocoll
PCI PKL 326
Mapei Ultrabond ECO V4 SP FIBER
Eurocol 643 Eurostar Fibre
Kiesel Okatmos Star 110
Ardex AF 2224
Murexin D495

In order to use an alternative adhesive, it is necessary to obtain clearance from us, as well as from the adhesive manufacturer, in written form.

Special Adhesion Systems

An adhesion with Sigan products, as well as with roll-on adhesives and fixation, falls under the category of bond-bed adhesives. Therefore, the ultimate strength of a wet-bed adhesive can never be achieved!

Uzin sigan 1/2/3/Elements/Elements Plus
Schönox iFloor
Wakol D3330

To minimize proportional changes in the floor covering, we recommend the following approach:

1. Ground preparation: In accordance with specific installation instructions of the respective manufacturer and with trade regulations. The manufacturer's directions must be strictly adhered to!
2. Acclimatization: allow the floor covering 48 hours in the installation space to acclimatize. Area of application must be kept free of direct sunlight before, during and for 12 hours after installation.

In cases where bonding and roll-on adhesives are used, we cannot accept responsibility for any proportional changes in our products!

(Date: 01.08.2019)

